

Quick links

<u>Overview</u> <u>Product Variant Matrix</u>

<u>Dimensions</u> <u>Installation</u>

Connector Information

Recycling and Environmental Protection



BADENIA 2

Overview

- 20x 16-bit analogue inputs
- 4x independent CAN ports
- Fast 1GB Ethernet Connectivity
- 4GB logging memory
- 2x LIN

Badenia 2 from Cosworth offers high-rate data logging, control, outputs and huge processing capabilities. Featuring up to 20 x analogue inputs, 4 x CAN ports, LIN, and 5 x digital inputs, Badenia 2 is an extremely capable data logger.

| Electrical data | |
|-------------------------|--|
| Operating Voltage | 6.6 to 31.5V |
| Current consumption*1 | ~572mA @ 14V |
| Communication | |
| Ethernet | 1x 1000MB/S 2x 100MB/S |
| CAN Ports | 4 x Independent CAN Ports Max BAUD rate; 1MBit/s 64 x Message Buffers per Port Software selectable 120Ω Resistor |
| LIN Ports | 2x LIN Bus Master |
| Serial Ports | 2 x Bi-Directional RS232 Ports Split Tx and Rx Rates Max BAUD Rate: 115200 |
| Debug | 1 x Bi-Directional RS232 Fixed@115200 BAUD Rate |
| Mechanical data | |
| Size | 118 x 120 x 34 mm |
| Weight | 472 grams |
| Environmental | IP66 |
| Vibration | Cosworth DV-V [©] |
| Case Material | 6082-T6 Anodized |
| Operating Internal Temp | -20°c to + 70°c |
| Storage Temp | -20°c to + 80°c |



Additionally, a selection of HSD/PWM outputs result in the Badenia 2 being the ideal unit for complete vehicle control.

| 1/0 | |
|------------------------|---|
| Logging Specifications | See Token Logging Options on page 3. |
| | 20 x 0-5 Inputs 16-bit resolution |
| Analogue Inputs | Filtered 3dB frequency of ~15.9kHz |
| | 2.1M Ω Impedance |
| | AIN 1-8 selectable 1K8 Pull Up |
| Digital Inputs | 4 x High Frequency (10kHz) supports hall effect /VRS/DF11i 1 x Support IR Lap Timing & Switches Selectable 3k3 pull-up to 5V or Level Shift for Passive Sensors |
| Excitations | 3 x 5V ±0.25% Supply @ 100mA 2 x Software Selectable 5V/12V 12V ±0.5% Supply @ 700mA |
| HSD / PWM | 2 x HSD / PWM Battery Voltage @ 700mA(max) 400Hz Maximum PWM Frequency |
| Motion Senor | Accelerometer 3 axis ±16G |
| Internal Monitoring | Battery Voltage Box Temperature Excitation Voltage |
| LEDs | 7 x System Status LEDs |

Product Variant Matrix

Token Logging Options

| Variant | 220 | 240 | 260 |
|----------------------------------|----------------|----------------|----------------|
| Token Part Number 01P-650100-220 | | 01P-650100-240 | 01P-650100-260 |
| Logging Capacity (MB) | 1,024 | 2,048 | 4,096 |
| Cont. Sampling Rate (Hz) | 1,000 | 1,000 | 1,000 |
| Cont. Bandwidth (bytes/sec) | 50,000 | 50,000 | 100,000 |
| High Speed Sampling Rates (Hz) | - | 2,000 | 5,000 |
| High Speed Bandwidth (bytes/sec) | - | 48,000 | 100,000 |
| No. of Burst Logging Tables | 1 | 1 | 1 |
| Total no. of Channels | 1,024 | 1,024 | 2,048 |
| Maths Channels | 100 | 200 | 500 |
| Logic Channels | Enabled | Enabled | Enabled |
| Analogue Inputs | 8 | 12 | 20 |
| Digital Inputs | 5 (4x Df11i) | 5 (4x Df11i) | 5 (4x Df11i) |
| CAN Ports | 2 | 3 | 4 |
| LIN Ports | 2 | 2 | 2 |
| Ethernet Displays | 48 | 48 | 48 |
| Auto Coding Customer | Upgrade option | Upgrade option | Upgrade option |
| Auto Coding Developer | Upgrade option | Upgrade option | Upgrade option |
| Telemetry Tables | - | - | 1 |

Ordering information

| Badenia 2 Series | 01L-650100 |
|--------------------------------|----------------|
| 220 Token | 01P-650100-220 |
| 240 Token | 01P-650100-240 |
| 260 Token | 01P-650100-260 |
| Auto Coding Developer Token | On Request |

Compatible devices

| CDU 4.3 | 01L-650100 |
|-----------------|------------|
| CDU 7.0 | 01L-650080 |
| CDU 10.3 | 01D-640060 |
| Centaurus 5 Mk2 | 01L-610140 |
| SJU | 01L-650050 |
| CCW Mk3 | 01D-641350 |

Software information


| <u></u> | Pi Toolset | Configuration software for power control and logging (v9 and above) |
|----------------------------------|------------|--|
| √ | Pi Toolbox | Professional Data Analysis (v10 and above) |
| API | | Cosworth DAE Engine for Real time Data pipelines. |
| Auto-Coding via MATLAB/Simulink® | | Customer auto-coding via MATLAB/ Simulink [®] and Cosworth Workspace Editor coming soon. |

LED Indicator Definitions



| Legend | Function | Sequence | Period |
|------------|---|-------------------|--------|
| _ | No power to the Unit | Off | |
| பு | Initialising and waiting for clock sync | On | |
| | Unit operational | 50% Flash (1Hz) | |
| | During startup a single flash LED test | Long Single Pulse | |
| <u>^!\</u> | Normal running operation | Off | |
| _ | Logger error or no dataset loaded | On | |
| | During startup a single flash LED test | Long Single Pulse | |
| | Normal running operation | Off | |
| | Logger full and overwriting data | On | |
| | 1000Base T. No connection established | Off | |
| | Connection established | 50% Flash (1Hz) | |
| | Communication active | Flickering | |
| | 100Base T. No connection established | Off | |
| ᅶ | Connection established | 50% Flash (1Hz) | |
| шш | Communication active | Flickering | |
| _ | 100Base T. No connection established | Off | |
| ᅷ | Connection established | 50% Flash (1Hz) | |
| шШ | Communication active | Flickering | |

Dimensions



Installation

- Make sure that the unit is protected against severe vibrations by mounting using supplied AV mounting kit. Also make sure that the unit is not fouling other structures which may experience severe vibrations.
- Make sure that the unit is mounted in a position where the unit will not come into contact with liquid.
- Make sure that the unit is positioned in an area with sufficient cooling air flow to prevent overheating.
- Make sure that the unit is mounted away from sources of electrical interference.

Connector information

Please note, pin allocation is in functional order, not pin number order.

CN1

| Connector | Mating connector |
|------------|------------------|
| AS214-35PN | AS614-35SN |

Connector information

| Pin | 220 | 240 | 260 | Description |
|-----|-----------|-----------|-----------|--|
| 6 | BATT+ | BATT+ | BATT+ | D-#+ |
| 22 | BATT+ | BATT+ | BATT+ | Battery supply +VE |
| 7 | BATT- | BATT- | BATT- | Battery supply –VE |
| 5 | ETH1000+1 | ETH1000+1 | ETH1000+1 | Ethernet 1000BaseT +ve for PC comms |
| 4 | ETH1000-1 | ETH1000-1 | ETH1000-1 | Ethernet 1000BaseT -ve for PC comms |
| 3 | ETH1000+2 | ETH1000+2 | ETH1000+2 | Ethernet 1000BaseT +ve for PC comms |
| 21 | ETH1000-2 | ETH1000-2 | ETH1000-2 | Ethernet 1000BaseT -ve for PC comms |
| 20 | ETH1000+3 | ETH1000+3 | ETH1000+3 | Ethernet 1000BaseT +ve for PC comms |
| 2 | ETH1000-3 | ETH1000-3 | ETH1000-3 | Ethernet 1000BaseT -ve for PC comms |
| 1 | ETH1000+4 | ETH1000+4 | ETH1000+4 | Ethernet 1000BaseT +ve for PC comms |
| 19 | ETH1000-4 | ETH1000-4 | ETH1000-4 | Ethernet 1000BaseT -ve for PC comms |
| 15 | ETH1-RX+1 | ETH1-RX+1 | ETH1-RX+1 | Ethernet 100BaseT for car comms RX+ |
| 14 | ETH1-RX-1 | ETH1-RX-1 | ETH1-RX-1 | Ethernet 100BaseT for car comms RX- |
| 28 | ETH1-TX+1 | ETH1-TX+1 | ETH1-TX+1 | Ethernet 100BaseT for car comms TX+ |
| 16 | ETH1-TX-1 | ETH1-TX-1 | ETH1-TX-1 | Ethernet 100BaseT for car comms TX- |
| 12 | ETH2-RX+2 | ETH2-RX+2 | ETH2-RX+2 | Ethernet 100BaseT for car comms RX+ |
| 26 | ETH2-RX-2 | ETH2-RX-2 | ETH2-RX-2 | Ethernet 100BaseT for car comms RX- |
| 27 | ETH2-TX+2 | ETH2-TX+2 | ETH2-TX+2 | Ethernet 100BaseT for car comms TX+ |
| 13 | ETH2-TX-2 | ETH2-TX-2 | ETH2-TX-2 | Ethernet 100BaseT for car comms TX- |
| 30 | CANH1 | CANH1 | CANH1 | CAN port 1 |
| 18 | CANL1 | CANL1 | CANL1 | CAN port I |
| 29 | CANH2 | CANH2 | CANH2 | CAN port 2 |
| 17 | CANL2 | CANL2 | CANL2 | CAN port 2 |
| 34 | N/A | CANH3 | CANH3 | CAN port 3 |
| 35 | N/A | CANL3 | CANL3 | CAN ports |
| 24 | N/A | N/A | CANH4 | CAN port 4 |
| 33 | N/A | N/A | CANL4 | CAN port 4 |
| 11 | N/A | N/A | N/A | Do Not Connect |
| 25 | N/A | N/A | N/A | Do Not Connect |
| 10 | LIN1 | LIN1 | LIN1 | LIN bus master 1 |
| 9 | LIN2 | LIN2 | LIN2 | LIN bus master 2 |
| 36 | RS232-TX1 | RS232-TX1 | RS232-TX1 | RS232 serial comms transmit data (Badenia to external) |
| 32 | RS232-TX2 | RS232-TX2 | RS232-TX2 | RS232 serial comms transmit data (Badenia to external) |
| 37 | RS232-RX1 | RS232-RX1 | RS232-RX1 | RS232 serial comms receive data (external to Badenia) |
| 31 | RS232-RX2 | RS232-RX2 | RS232-RX2 | RS232 serial comms receive data (external to Badenia) |
| 8 | DEBTX | DEBTX | DEBTX | Debug comms transmit data |
| 23 | DEBRX | DEBRX | DEBRX | Debug comms receive data |

Connector information

Please note, pin allocation is in functional order, not pin number order.

CN2

| Connector | Mating connector |
|------------|------------------|
| AS214-35SN | AS614-35PN |

| Pin | 220 | 240 | 260 | Description |
|-----|-------------|-------------|-------------|---|
| 26 | AIN1 | AIN1 | AIN1 | |
| 12 | AIN2 | AIN2 | AIN2 | |
| 25 | AIN3 | AIN3 | AIN3 | 8 x Analogue inputs |
| 11 | AIN4 | AIN4 | AIN4 | Software selectable 1K8 pull-up resistor |
| 9 | AIN5 | AIN5 | AIN5 | Input filter 234kHz ADC filter response 22.5kHz |
| 10 | AIN6 | AIN6 | AIN6 | 0 to 5v input with 16-bit resolution |
| 8 | AIN7 | AIN7 | AIN7 | 0 to 50 input with 10-bit resolution |
| 24 | AIN8 | AIN8 | AIN8 | |
| 7 | N/A | AIN9 | AIN9 | |
| 23 | N/A | AIN10 | AIN10 | |
| 22 | N/A | AIN11 | AIN11 | |
| 6 | N/A | AIN12 | AIN12 | |
| 21 | N/A | N/A | AIN13 | 12 x Analogue inputs |
| 5 | N/A | N/A | AIN14 | Input filter 234kHz |
| 20 | N/A | N/A | AIN15 | ADC filter 22.5kHz |
| 4 | N/A | N/A | AIN16 | 0 to 5v input with 16-bit resolution |
| 2 | N/A | N/A | AIN17 | |
| 3 | N/A | N/A | AIN18 | |
| 1 | N/A | N/A | AIN19 | |
| 19 | N/A | N/A | AIN20 | |
| 17 | DIGIN1 | DIGIN1 | DIGIN1 | / Distal is suite |
| 18 | DIGIN2 | DIGIN2 | DIGIN2 | 4 x Digital inputs DF11i, Selectable 3k3 pull-up to 5v or level shift for |
| 36 | DIGIN3 | DIGIN3 | DIGIN3 | passive sensors |
| 30 | DIGIN4 | DIGIN4 | DIGIN4 | passive serisors |
| 35 | DIGIN5 | DIGIN5 | DIGIN5 | Digital input level. IR lap timing and switches. 3k3 pull-up |
| 16 | HSD1 | HSD1 | HSD1 | 400Hz PWM maximum switching rate Switches between |
| 29 | HSD2 | HSD2 | HSD2 | ground and battery voltage @700mA |
| 13 | EXT5PSU1 | EXT5PSU1 | EXT5PSU1 | |
| 14 | EXT5PSU2 | EXT5PSU2 | EXT5PSU2 | 3 x 5v excitation @100mA |
| 27 | EXT5PSU3 | EXT5PSU3 | EXT5PSU3 | |
| 15 | EXT5/12PSU1 | EXT5/12PSU1 | EXT5/12PSU1 | 2 x 5v or 12v software selectable excitation 5v @ 100mA, |
| 28 | EXT5/12PSU2 | EXT5/12PSU2 | EXT5/12PSU2 | 12v @ 700mA |
| 31 | Sensor GND | Sensor GND | Sensor GND | |
| 32 | Sensor GND | Sensor GND | Sensor GND | 5 x Grounds These are all common connections which |
| 33 | Sensor GND | Sensor GND | Sensor GND | can be used for any ground connection |
| 34 | Sensor GND | Sensor GND | Sensor GND | can be used for any ground confidention |
| 37 | Sensor GND | Sensor GND | Sensor GND | |

Recycling and Environmental Protection

Cosworth Electronics is committed to conducting its business in an environmentally responsible manner and strive for high environmental standards.

Manufacture: Cosworth products comply with the appropriate requirements of the Restriction of Hazardous Substance (RoHS).

Disposal: Electronic equipment should be disposed of on accordance with the regulations in force and in particular in accordance with the Waste in Electrical and Electronic Equipment directive. (WEEE).


Battery

This equipment contains a rechargeable battery (Manganese Silicon Lithium).

The equipment may be returned to Cosworth Electronics for a replacement battery. A charge will be made for this service

- To remove the battery for recycling:
- Remove the case(s).
- Remove printed circuit boards from the case.
- Remove the battery from the printed circuit board.
- Dispose of the battery in accordance with the regulations in force.

Removal of the battery will result in the warranty of the unit being void.



Document: 29L-650100-P

Rev: 4

All Information in this document is correct as of 21/08/2024

T (UK) +44 (0) 1604 598 300

T (US) +1 (317) 644 1037

E enquiries@cosworth.com

W www.cosworth.com

© Copyright Cosworth Electronics Ltd | All Content is Proprietary and Confidential. Brookfield Technology Centre, Twentypence Road, Cottenham, Cambridge, CB24 8PS.

